

FITTING INSTRUCTIONS

EINBAUANLEITUNG

INSTRUCCIONES DE MONTAJE

NOTICE DE MONTAGE

ISTRUZIONI DI MONTAGGIO

INSTRUKCJA MONTAŻU

INSTRUÇÕES DE MONTAGEM

ИНСТРУКЦИЯ ПО УСТАНОВКЕ

micronAir®

Audi	A3	05.03	->	21653024
Audi	Q3	09.11	->	CP1129
Audi	TT	09.06	->	MP113
Seat	Alhambra	08.10	->	
Seat	Altea	06.04	->	21653008
Seat	Altea Freetrack	06.04	->	CC1129
Seat	Altea XL	06.04	->	MC613
Seat	Leon	08.05	->	
Seat	Toledo III	05.03	->	49408561
Skoda	Octavia II	06.04	->	CB1129
Skoda	Superb II	07.08	->	BL613
Skoda	Yeti	08.09	->	
Volkswagen	Beetle	10.11	->	
Volkswagen	Caddy III	02.04	->	
Volkswagen	Caddy IV	09.10	->	
Volkswagen	CC	02.12	->	
Volkswagen	Eos III	03.04	->	
Volkswagen	Golf V	10.03	->	
Volkswagen	Golf VI	10.08	->	
Volkswagen	Golf VI Cabrio	10.08	->	
Volkswagen	Golf V Plus	01.05	->	
Volkswagen	Jetta III	08.05	->	
Volkswagen	Jetta IV	01.11	->	
Volkswagen	Passat	01.05	->	
Volkswagen	Passat CC	11.10	->	
Volkswagen	Passat CC	01.05	->	
Volkswagen	Scirocco III	04.08	->	
Volkswagen	Sharan II	03.04	->	
Volkswagen	Sharan II	08.10	->	
Volkswagen	Tiguan	11.07	->	
Volkswagen	Touran	02.03	->	

Audi, Altea, Golf, Oktavia, Toledo

