



filter **NC2301**  
**Land Rover Freelander**  
**(09/97→)**

Per il montaggio procedere eseguendo le operazioni in senso inverso.  
*Continuamente in reverse order of operations*  
 Le remontage s'effectue dans l'ordre inverse.  
*Der weitere Einbau erfolgt in umgekehrter Reihenfolge*  
 Para concluir la instalación, seguir el orden inverso.

