



## filter NC2392CA

**VOLVO V40 (03/12→)**  
**FORD Focus III (2011→)**  
**FORD CMAX II (2010→)**  
**FORD KUGA II (2012→)**

Per il montaggio procedere eseguendo le operazioni in senso inverso.

*Continuomounting in reverse order of operations*

Le remontage s'effectue dans l'ordre inverse.

*Der weitere Einbau erfolgt in umgekehrter Reihenfolge*

Para concluir la instalación, seguir el orden inverso.

