

FITTING INSTRUCTIONS
 EINBAUANLEITUNG
 INSTRUCCIONES DE MONTAJE
 NOTICE DE MONTAGE
 ISTRUZIONI DI MONTAGGIO
 INSTRUKCJA MONTAŻU
 INSTRUÇÕES DE MONTAGEM
 ИНСТРУКЦИЯ ПО УСТАНОВКЕ

micronAir[®]

Fiat
 500 L
 500 X

09.12 ->
 02.15 ->

80004572
 CP1462
 MP440

Jeep
 Renegade
 Compass

09.14 ->
 09.16 ->

80004719
 CC1462
 MC940

49408511
 CB1462
 BL940

