

FITTING INSTRUCTIONS
 EINBAUANLEITUNG
 INSTRUCCIONES DE MONTAJE
 NOTICE DE MONTAGE
 INSTRUZIONI DI MONTAGGIO
 INSTRUKCJA MONTAŻU
 INSTRUÇÕES DE MONTAGEM
 ИНСТРУКЦИЯ ПО УСТАНОВКЕ

micronAir®

Audi	A1	08.10 ->	80001783
Seat	Ibiza (5J5)	10.10 ->	CP1436
Seat	Toledo	10.12 ->	MP400
Skoda	Fabia	08.10 ->	
Skoda	Fabia	09.14 ->	80001784
Skoda	Praktik	06.07 ->	CC1436
Skoda Rapid	NH3	10.12 ->	MC900
Skoda Rapid	NH3 Spaceback	09.13 ->	
Skoda	Roomster	08.10 ->	49408488
Volkswagen	Polo (6R)	06.10 ->	CB1436
			BL900

