

VCF173

Makes/ Models

Filter Type:	Carbon
--------------	--------

<u>Audi</u> A3 Mk1 (1996->2003)

<u>Skoda</u> Octavia Mk1 (1998->2005) Superb (2002->)
--

<u>Volkswagen</u> Golf Mk3 (1992->1999) Passat Mk4 (1997->2000) Passat Mk5 (2001->2005)

<u>SEAT</u> Cordoba Mk1 (1994->2001) Leon Mk1 (2000->2005) Toledo Mk2 (1999->2005)
--

Difficulty:	Easy
Time (Approx)	5 Mins

Cabin Filter Location



1. The Cabin filter can be found in the engine compartment at the base of the windscreen.
2. Remove the rubber bonnet seal and hinge the plastic cover upwards.
3. Unclip the filter carrier and lift out to replace the filter.