

Service Information XTend clutch Disable wear compensation (special tool)





Fig. 1: XTend clutch with with special tool (example)

1 Special tool

## Disable wear compensation during removal

Depending on the XTend variant, it is necessary to use a special tool for the removal.

Examples:

| Opel    | 1.6 CDTi              | 3000 950 669 |
|---------|-----------------------|--------------|
| Peugeot | 1.6 HDi / 1.6 BlueHDi | 3000 950 671 |

## NOTICE

The special tool (1) jams the adjusting mechanism and thus prevents unintended adjustment of the wear compensation. Perform removal for the purpose of reutilization or survey only with the special tool (1). The special tool is available at your vehicle manufacturer.

1. Special tool (1) insert (Fig. 1).

→ adjusting mechanism is jammed.

- 2. Remove XTend clutch. Observe the vehicle manufacturer specifications.
- 3. Remove special tool (1).



www.aftermarket.zf.com/serviceinformation