








EASYVISION

CONNECTION TYPE 1 : Push Button 22mm




Connector CR1211 - Prefitted








EASYVISION

CONNECTION TYPE 2 : Pinch Tab/Top Lock



Connector CR1211 - Prefitted




www.championeasyvision.com









EASYVISION

CONNECTION TYPE 3 : Top Lock BMW



Connector CR1211 - Prefitted




www.championeasyvision.com








EASYVISION

CONNECTION TYPE 4 : Side Pin 19mm




Connector CR1211 - Prefitted







EASYVISION

CONNECTION TYPE 5 : Side Pin 22mm




Connector CR1211 + Cover CR1212









EASYVISION

CONNECTION TYPE 6 : Push Button 19mm




Connector CR1209 - Supplied Loose









EASYVISION

CONNECTION TYPE 7 : Flat Bayonet



Connector CR1207 - Supplied Loose



www.championeasyvision.com

