


## **IMPORTANT INSTALLATION NOTICE**

### **Automatic transmission filter with oil pan**

### **8020015 and 8020016**

Uptight mounted oil pans cause oil leaks and cracks in the oil pan itself. **Note the tightening sequence during installation!**



**Tightening sequence:** Keep oil pan on the gearbox and screw all screws in by hand. Check correct fitment of the oil pan. Start fasten screws at position 1 crosswise from inside to outside. Torque 10 NM. The car manufacturer's instructions must be observed.

Leaks or cracks through uptight mounted oil pans are not recognized as a guarantee case.