IIIIcal data call be subject to change

NEW PRODUCT HIGHLIGHT | JUL2019





to fit: Various VAG models





Breather Valve Kit

Function

The crankcase ventilation valve is used to direct hydrocarbons from the engine to the induction system, to be burnt rather than released into the atmosphere, reducing vehicle emissions.

Cause of failure

If the valve becomes blocked this can cause excess crankcase pressure within the engine, causing an increase in oil consumption and a decrease in engine performance. The connecting hose is continuously exposed to heat cycles and vibration when the engine is operating, this can cause the hose to split which will then release oil vapour into the engine bay area.