



Backverbare



Radio Code



FUNKTIONEN KONTROLLIEREN
FUNKTIONSTEST
CHECK FUNKTIONS
CONTROLEER FUNCTIES


MERCEDES W210/S210 1995- CLK C208 1997-

727173



727014

- D** Einbauanweisung
Elektrischer Zubehörsatz
- GB** Installation Instructions
Electrical Accessories Set
- F** Instructions de montage
Jeu d'accessoires électriques
- I** Istruzioni di montaggio
Kit di montaggio elettrico
- E** Instrucciones de montaje
Juego de accesorios eléctrico
- NL** Inbouwhandleiding
Elektrisch Toebehoorpakket


BRiNK®




INFO + ROUTING W210 / S210





W210 + S210



C208




- X kann 4-, 12- oder 18-polig sein
Siehe in der Tabelle für die richtige Position
- X kan vara 4-, 12- eller 18 pol
se tabell för rätt position
- X can be 4-, 12- or 18-pole
See table for the right position
- X kan 4-, 12- of 18-polig zijn
Voor de juiste positie zie tabel




| Poles | X | Position |
|-------|---|----------|
| 4 | → | 2 |
| 12 | → | 2 |
| 18 | → | 15 |


INFO + ROUTING C208




W210




S210




W210+S210




C208




13p



13p




13p




13p

W210+S210







13p

C208





13p

OPTIE 208




*Rot
*rouge
*red
*rood


C208





10 mm



Code




C208



W210


S210

C208






W210+S210

C208



W210+S210



C208

