

DONNEES TECHNIQUES

Type de réseau de bord	pour véhicules 12V
Puissance nominale [kW]	1.1
Nombre de dents	10T
Direction de rotation	rotation CW
Réducteur	Avec réducteur (G/R) intégré
Nombre de taraudages	3
Nombre de trous de fixation	3
Connectique	SOL66


PHOTOS



BULLETIN TECHNIQUE TB-05

Ce démarreur n'utilise pas de bobinage en cuivre ou en aluminium, mais utilise des aimants ferreux permanents. Si vous traitez ce démarreur brutalement (chute ou coup de marteau sur le démarreur ou le solénoïde), les aimants se fissureront ou casseront. Ceci entraînant la destruction du démarreur.

This starter doesn't use field coils made from copper or aluminium, but uses ferrite permanent magnets. If you treat this starter roughly (e.g. drop or hit on the starter motor or solenoid with a hammer) the magnets will crack or break. Causing the starter to fail.




DOCUMENTS

BT-130 Refus des carcasses alternateurs/démarrateurs

APPLICATIONS

FORD		
ESCORT 91 Courrier (AVL) - 1.4	71 ch	07.1990 > 12.1994
ESCORT 95 Courrier (AVL) - 1.4	73 ch	01.1995 >
ESCORT (90-92) (GAL) - 1.4	71 ch	07.1990 > 09.1992
ESCORT (90-92) (GAL) - 1.6	90 ch	07.1990 > 08.1992
	105 ch	07.1990 > 12.1992
ESCORT (90-92) (GAL) - 1.8 16V XR3i	105 ch	02.1992 > 12.1992
	130 ch	02.1992 > 12.1992
ESCORT (90-92) Break (GAL, AVL) - 1.4	71 ch	07.1990 > 09.1992
ESCORT (90-92) Break (GAL, AVL) - 1.6	90 ch	07.1990 > 08.1992
	105 ch	07.1990 > 09.1992
ESCORT (90-92) Cabriolet (ALL) - 1.4	71 ch	07.1990 > 12.1992
ESCORT (90-92) Cabriolet (ALL) - 1.6	105 ch	07.1990 > 12.1992
ESCORT (90-92) Cabriolet (ALL) - 1.8 16V XR3i	130 ch	02.1992 > 12.1992
ESCORT (92-95) (GAL) - 1.4	71 ch	09.1992 > 01.1995
ESCORT (92-95) (GAL) - 1.6 i 16V	88 ch	01.1994 > 01.1995
	90 ch	09.1992 > 01.1995
ESCORT (92-95) (GAL) - 1.8 16V XR3i	130 ch	09.1992 > 01.1995
ESCORT (92-95) (GAL) - 1.8 i 16V	105 ch	09.1992 > 01.1995
ESCORT (92-95) (GAL) - 1.8 XR3i 16V 4x4	105 ch	08.1993 > 01.1995
ESCORT (92-95) 3 volumes (GAL) - 1.4	71 ch	08.1993 > 04.1994
	75 ch	08.1993 > 01.1995
ESCORT (92-95) 3 volumes (GAL) - 1.6 i 16V	88 ch	01.1994 > 01.1995
	90 ch	08.1993 > 01.1995
ESCORT (92-95) 3 volumes (GAL) - 1.8 i 16V	105 ch	08.1993 > 01.1995
ESCORT (92-95) Break (GAL) - 1.4	71 ch	09.1992 > 01.1994
	75 ch	01.1994 > 01.1995
ESCORT (92-95) Break (GAL) - 1.6 i 16V	88 ch	01.1994 > 01.1995
	90 ch	09.1992 > 01.1995
ESCORT (92-95) Break (GAL) - 1.8 i 16V	105 ch	01.1993 > 01.1995
ESCORT (92-95) Cabriolet (ALL) - 1.4	71 ch	12.1992 > 04.1994
ESCORT (92-95) Cabriolet (ALL) - 1.4 i	75 ch	07.1993 > 01.1995
ESCORT (92-95) Cabriolet (ALL) - 1.6 16V XR3i	90 ch	12.1992 > 01.1995
ESCORT (92-95) Cabriolet (ALL) - 1.6 i 16V	88 ch	02.1994 > 01.1995
ESCORT (92-95) Cabriolet (ALL) - 1.8 16V XR3i	105 ch	12.1992 > 01.1995
	130 ch	12.1992 > 01.1995
ESCORT (95-00) (GAL, AAL, ABL) - 1.4	75 ch	01.1995 > 10.1998
ESCORT (95-00) 3 volumes (GAL, AFL) - 1.4	75 ch	01.1995 > 02.1999
ESCORT (95-00) Clipper (GAL, ANL) - 1.4	75 ch	01.1995 > 02.1999
FIESTA (83-89) (FBD) - 1.4	69 ch	09.1983 > 01.1987
FIESTA (83-95) Camionnette (FVD) - 1.4	71 ch	09.1986 > 09.1989
FIESTA (89-97) (GFJ) - 1.4	73 ch	03.1989 > 12.1995
FIESTA (89-97) (GFJ) - 1.6	88 ch	01.1989 > 01.1994
	90 ch	03.1989 > 12.1992
FIESTA (89-97) (GFJ) - 1.6 i 16V	88 ch	01.1994 > 12.1995
FIESTA (89-97) (GFJ) - 1.6 XR2i	103 ch	03.1989 > 03.1993
	110 ch	03.1989 > 01.1994
FIESTA (89-97) (GFJ) - 1.8 16V	105 ch	02.1992 > 12.1995
FIESTA (89-97) (GFJ) - 1.8 XR2i 16V	130 ch	02.1992 > 12.1995

FORD		
ORION (90-93) (GAL) - 1.4	71 ch	07.1990 > 12.1993
	73 ch	07.1990 > 12.1993
ORION (90-93) (GAL) - 1.6 i 16V	90 ch	07.1992 > 12.1993
ORION (90-93) (GAL) - 1.8 i 16V	105 ch	02.1992 > 12.1993
	130 ch	01.1992 > 12.1993

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.