

## DONNEES TECHNIQUES

Type de réseau de bord	<b>pour véhicules 12V</b>
Puissance nominale [kW]	<b>0.95</b>
Nombre de dents	<b>8T</b>
Direction de rotation	<b>rotation CW</b>
Nombre de taraudages	<b>2</b>
Nombre de trous de fixation	<b>3</b>
Connectique	<b>SOL65</b>


## PHOTOS



### BULLETIN TECHNIQUE TB-05

Ce démarreur n'utilise pas de bobinage en cuivre ou en aluminium, mais utilise des aimants ferreux permanents. Si vous traitez ce démarreur brutalement (chute ou coup de marteau sur le démarreur ou le solénoïde), les aimants se fissureront ou casseront. Ceci entraînant la destruction du démarreur.

This starter doesn't use field coils made from copper or aluminium, but uses ferrite permanent magnets. If you treat this starter roughlyly (e.g. drop or hit on the starter motor or solenoid with a hammer) the magnets will crack or break. Causing the starter to fail.




## DOCUMENTS

**BT-130 Refus des carcasses alternateurs/démarrateurs**

## APPLICATIONS

<b>KIA</b>		
CARENS (02-06) (FJ, RS) - 1.6	105 ch	07.2002 >
CLARUS (K9A) - 1.8 i 16V	116 ch	07.1996 >
CLARUS (K9A) - 2.0 i 16V	133 ch	07.1996 >
CLARUS Break (GC) - 1.8 i 16V	116 ch	05.1998 >
CLARUS Break (GC) - 2.0 i 16V	133 ch	05.1998 >
SEPHIA (93-97) (FA) - 1.5 i	80 ch	02.1996 > 10.1997
SEPHIA (93-97) (FA) A 3 Volumes - 1.5 i	80 ch	02.1996 > 10.1997
SEPHIA (93-97) (FA) A 3 Volumes - 1.6 i	80 ch	09.1993 > 10.1997
SHUMA (97-04) (FB) - 1.5 i 16V	88 ch	10.1997 > 03.2001
SHUMA (97-04) (FB) A 3 Volumes - 1.5 i 16V	88 ch	10.1997 > 10.2001
SPORTAGE (93-04) (K00) - 2.0 4WD	118 ch	10.2000 > 08.2003
SPORTAGE (93-04) (K00) - 2.0 i 16V	128 ch	10.1999 > 08.2003
SPORTAGE (93-04) (K00) - 2.0 i 16V 4WD	128 ch	04.1994 > 08.2003
SPORTAGE (93-04) (K00) - 2.0 i 4WD	95 ch	04.1994 > 08.1999
<b>MAZDA</b>		
323 (80-85) (BD) - 1.1	54 ch	11.1980 > 10.1985
323 (80-85) (BD) - 1.3	60 ch	09.1981 > 10.1985
	68 ch	11.1980 > 10.1989
323 (80-85) (BD) - 1.5	75 ch	05.1981 > 12.1985
	80 ch	11.1980 > 07.1985
	88 ch	03.1982 > 09.1986
323 (80-85) Hatchback (BD) - 1.1	54 ch	11.1980 > 10.1985
323 (80-85) Hatchback (BD) - 1.3	60 ch	11.1980 > 10.1985
	68 ch	11.1980 > 10.1989
323 (80-85) Hatchback (BD) - 1.5	75 ch	05.1981 > 07.1985
	80 ch	08.1982 > 04.1985
	86 ch	11.1980 > 12.1983
	88 ch	03.1982 > 12.1985
323 (85-89) (BF) - 1.3	60 ch	08.1985 > 05.1989
323 (85-89) (BF) - 1.5	73 ch	09.1987 > 10.1989
	75 ch	08.1985 > 05.1989
323 (85-89) (BF) - 1.6 GT	85 ch	11.1986 > 10.1989
323 (85-89) (BF) - 1.6 GT Turbo	140 ch	10.1985 > 11.1991
323 (85-89) Break (BW) - 1.5	73 ch	01.1987 > 05.1989
	75 ch	05.1986 > 05.1989
323 (85-89) Break (BW) - 1.6	86 ch	09.1986 > 10.1995
323 (85-89) Hatchback (BF) - 1.3 i	67 ch	09.1985 > 08.1989
323 (85-89) Hatchback (BF) - 1.4	60 ch	09.1987 > 10.1989
323 (85-89) Hatchback (BF) - 1.5	73 ch	09.1987 > 10.1989
	75 ch	08.1985 > 05.1989
323 (85-89) Hatchback (BF) - 1.6	73 ch	09.1987 > 10.1989
323 (85-89) Hatchback (BF) - 1.6 GT	86 ch	09.1987 > 10.1989
323 (89-94) C (BG) - 1.3	67 ch	09.1989 > 07.1994
323 (89-94) C (BG) - 1.3 16V	73 ch	09.1989 > 07.1994
323 (89-94) C (BG) - 1.6 16V	88 ch	03.1991 > 10.1994
323 (89-94) C (BG) - 1.8 16V	140 ch	09.1989 > 03.1993
323 (89-94) C (BG) - 1.8 16V Turbo 4WD	163 ch	09.1990 > 12.1992

<b>MAZDA</b>		
323 (89-94) F (BG) - 1.6 16V	88 ch	03.1991 > 10.1994
323 (89-94) F (BG) - 1.8 16V	140 ch	09.1989 > 03.1993
323 (89-94) S (BG) - 1.3	67 ch	09.1989 > 06.1991
323 (89-94) S (BG) - 1.3 16V	73 ch	04.1991 > 07.1994
323 (89-94) S (BG) - 1.6 16V	88 ch	08.1989 > 10.1994
323 (89-94) S (BG) - 1.8 16V Turbo 4WD	163 ch	01.1991 > 07.1994
323 (94-98) C (BA) - 1.3 16V	73 ch	08.1994 > 09.1998
323 (94-98) P (BA) - 1.3 16V	73 ch	10.1996 >
323 (94-98) P (BA) - 1.5 16V	88 ch	10.1996 >
323 (94-98) S (BA) - 1.3 16V	73 ch	08.1994 > 09.1998
323 (94-98) S (BA) - 1.5 16V	88 ch	08.1994 > 09.1998
323 (98-04) F (BJ) - 1.4	72 ch	01.2001 > 05.2004
323 (98-04) F (BJ) - 1.4 16V	73 ch	09.1998 > 01.2001
323 (98-04) F (BJ) - 1.5 16V	88 ch	09.1998 > 01.2001
323 (98-04) F (BJ) - 1.6	95 ch	01.2001 > 05.2004
	98 ch	01.2001 > 05.2004
323 (98-04) S (BJ) - 1.4 16V	73 ch	09.1998 > 01.2001
323 (98-04) S (BJ) - 1.5 16V	88 ch	09.1998 > 01.2001
323 (98-04) S (BJ) - 1.6	95 ch	01.2001 > 05.2004
	98 ch	01.2001 > 05.2004
626 (88-92) Break (GV) - 2.0 12V	110 ch	09.1987 > 01.1990
626 (88-92) Break (GV) - 2.0 i 16V	150 ch	11.1994 > 09.1997
B-SERIE (85-98) (UF) - 2.0	84 ch	01.1985 > 12.1991
	88 ch	01.1985 > 03.1996
DEMIO (DW) - 1.3 16V	63 ch	08.1998 >
	72 ch	08.1998 > 04.2000

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.