

DONNEES TECHNIQUES

Type de réseau de bord	pour véhicules 12V
Puissance nominale [kW]	1.4
Nombre de dents	8/10T
Direction de rotation	rotation CW
Réducteur	Avec réducteur (G/R) intégré
Nombre de taraudages	2
Nombre de trous de fixation	3
Connectique	SOL65


PHOTOS



BULLETIN TECHNIQUE TB-05

Ce démarreur n'utilise pas de bobinage en cuivre ou en aluminium, mais utilise des aimants ferreux permanents. Si vous traitez ce démarreur brutalement (chute ou coup de marteau sur le démarreur ou le solénoïde), les aimants se fissureront ou casseront. Ceci entraînant la destruction du démarreur.

This starter doesn't use field coils made from copper or aluminium, but uses ferrite permanent magnets. If you treat this starter roughly (e.g. drop or hit on the starter motor or solenoid with a hammer) the magnets will crack or break. Causing the starter to fail.




DOCUMENTS

BT-130 Refus des carcasses alternateurs/démarrateurs

APPLICATIONS

KIA		
CLARUS Break (GC) - 1.8 i 16V	116 ch	05.1998 >
CLARUS Break (GC) - 2.0 i 16V	133 ch	05.1998 >
ROADSTER - 1.8	136 ch	08.1999 >
SEPHIA (93-97) (FA) - 1.8 i 16V	112 ch	01.1995 > 10.1997
SEPHIA (93-97) (FA) A 3 Volumes - 1.8 i 16V	112 ch	01.1995 > 10.1997
MAZDA		
323 (89-94) F (BG) - 1.8 4WD	103 ch	01.1991 > 04.1994
323 (98-04) S (BJ) - 2.0	131 ch	01.2001 > 05.2004
626 (88-92) (GD) - 2.0 12V	107 ch	09.1987 > 05.1992
626 (88-92) (GD) - 2.2 12V	115 ch	11.1987 > 07.1991
626 (88-92) Break (GV) - 2.0 12V	110 ch	09.1987 > 01.1990
626 (88-92) Break (GV) - 2.0 16V	140 ch	01.1988 > 03.1992
626 (88-92) Break (GV) - 2.2 12V	115 ch	03.1989 > 11.1996
626 (88-92) Break (GV) - 2.2 12V 4WD	116 ch	05.1991 > 11.1992
626 (88-92) Coupe (GD) - 2.0	90 ch	09.1987 > 10.1990
626 (88-92) Coupe (GD) - 2.0 12V	107 ch	09.1987 > 12.1988
626 (88-92) Coupe (GD) - 2.2 12V	115 ch	04.1988 > 12.1991
626 (88-92) Hatchback (GD) - 2.0 12V	107 ch	11.1987 > 05.1992
626 (88-92) Hatchback (GD) - 2.0 16V	140 ch	11.1987 > 10.1990
626 (88-92) Hatchback (GD) - 2.2 12V	115 ch	06.1988 > 04.1992
626 (93-97) (GE) - 1.8 i	90 ch	08.1994 > 04.1997
	105 ch	01.1992 > 04.1997
626 (93-97) (GE) - 2.0 i	115 ch	01.1992 > 04.1997
626 (93-97) (GE) - 2.0 i 4WD	116 ch	04.1992 > 04.1997
626 (93-97) Hatchback (GE) - 1.8	90 ch	08.1994 > 04.1997
	105 ch	08.1991 > 04.1997
626 (93-97) Hatchback (GE) - 2.0 i	115 ch	08.1991 > 04.1997
626 (93-97) Hatchback (GE) - 2.0 i 4WD	116 ch	04.1992 > 04.1997
MX-6 (92-97) (GE6) - 2.0	115 ch	02.1992 >
PREMACY (CP) - 2.0	131 ch	11.2001 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.