



1




- Clean the cooling system.
- Limpiar el circuito de refrigeración.
- Reinigen Sie das Kühlsystem.
- Nettoyer le système de refroidissement.

2




Disassemble the water pump


3




Clean the block engine




Check that it is the same part




Not use silicone joint if there is gasket



Right order



Timing belt assembly and check timing belt



No water allowed



Use the right coolant