

LVCF532

Filter Type:	Standard
--------------	----------

Time (Approx):	40 mins
----------------	---------



1. The cabin filter is located behind the glove box.
2. Remove the glove box to access the filter.