

VCF127

Makes/ Models

Filter Type: Standard

Peugeot

206 (1998->)

Peugeot LCV

206 (2000->)

Difficulty: Easy
Time (Approx) 1 Mins

Cabin Filter Location



1. Cabin Filter is located in the engine compartment under the scuttle.
2. Is located under the air vent slots and is clearly visible when bonnet is open.