

XCS6022 SPECIFICATION

	SUPPLY VOLTAGE	12V
	RESISTANCE	1 Kohm
	AIR GAP	1.5 +/- 0.2mm
	MAX OUTPUT VOLTAGE	11.60 +/- 0.2V
	MIN OUTPUT VOLTAGE	0.20 +/- 0.2V







Pin 1 VCC Pin 2 OUT Pin 3 GND



IMPORTANT FITTING ADVICE FOLLOWS





XCS6022 IMPORTANT FITTING INFORMATION



Please ensure that the locating lug is positioned correctly before securing into place.

Failure to correctly locate the lug or shearing off the lug will result in misalignment of the sensor and faulty readings.



PLEASE READ THE FOLLOWING GENERAL FITTING ADVICE...



CAMSHAFT SENSOR GENERAL FITTING ADVICE





BATTERY



INDUCTIVE SENSOR



HALL EFFECT SENSOR



- Camshaft sensor failure is commonly caused by damage from oil contamination. Ensure any oil leaks are addressed before replacing the sensor.
- 2. Carefully remove the old sensor.
- 3. Oil the 'O' ring of the new sensor
- 4. Correct positioning of the new sensor is critical. Camshaft sensors often feature slotted mounting holes and/or locating pins. Ensure that any locating pins are correctly seated before fully slotting into place. Failure to do so can shear off the locating pin causing misalignment of the sensor and incorrect readings.
- 5. Reconnect wiring and reset the ECU if needed. (See next page)



IF FAULTS PERSIST A PARAMETER RESET MAY BE REQUIRED. PLEASE SEE NEXT PAGE



RESET PARAMETERS GENERAL ADVICE

After replacing engine management components, many vehicles will require a reset of the parameters to tell the ECU that a new part has been fitted. Without this, the ECU will believe that the engine is still running with faulty sensors and will default back to data already received before the replacement. This causes the vehicle to run poorly, normally with the Malfunction Indicator Lamp on and the fault code still logged in memory.



ALWAYS REFER TO MANUFACTURERS INSTRUCTIONS

Reset parameters as follows

- 1. Firstly, reset the vehicle using diagnostic tools.
- 2. If the fault code persists, perform a manual reset according to the manufacturers instructions, commonly as follows:
- Carry out 3 drive cycles:
 A. Turn ignition on, turn ignition off
 B. Turn ignition on, turn ignition off
 C. Start the engine.
- 4. An extended road test, normally around 20 miles is then required to provide the ECU with enough data to allow the sensor to function correctly.

TECHASSIST

"Fitting aftermarket sensors is similar to plugging an aftermarket device into a PC or laptop – the PC will recognise the new device, then find and install the drivers it needs to operate correctly. The vehicle's ECU is very similar, it simply needs to calculate how best to use the newly fitted component."